




● Guideline on Antenna direction




When locating higher than 2m+ on camera tripod/light stand/mic stand, frame structure etc. : Optimize the signal for all the front, back and side



When installing on the ceiling:
Optimize the signal for every side of downward



When installing on the ceiling:
Optimize the signal for the front and downside.
Bend the TX antenna 90 degree downward and RX antenna 90 degree to side



Optimize the signal for the front and back



Optimize the signal for the front and upward
Bend the TX antenna 90 degree upward
and RX antenna 90 degree to sideward



Weaken the signal
when the BP are located very close from the Base Station