

## BP750/150 BELT PACK ISO OPERATIONS & LED INDICATIONS

### A. In Handsfree Off(PTT) Mode

#	BP set up/Button Operation	FUNCTION	STATUS	LED STATUS
1	Selecto two groups in the TWO GROUPS menu(ie:1&2)	ISO	Listening(RX) both groups at the same time selected in the TWO GROUPS menu	Green LED blinking
2	Pressing 'TALK' button on the BP while talking	Talk(TX) to the former group (ie: 1)	Listening both groups but talking to the former groups (ie. 1) only	Green LED on
3	Pressing 'GRP' button on the BP while talking	Talk(TX) to the latter group (ie: 2)	Listening both groups but talking to the latter groups (ie. 2) only	Orange LED on
4	Pressing both 'TALK' and 'GRP' button while talking	Talk to the both groups	Listening both groups and talking to both groups as well	Orange quick blink

※ The operations are active while the BP screen shows initial 'Normal menu' or in sleep mode.

### B. In Handsfree ON Mode

#	BP set up/Button Operation	FUNCTION	STATUS	LED STATUS
1	Selecto two groups in the TWO GROUPS menu(ie:1&2)	ISO	Listening(RX) both groups at the same time selected in the TWO GROUPS menu	Green LED blinking
2	Press 'TALK' button once	Talk(TX) to the former group (ie: 1)	Listening both groups but talking to the former groups (ie. 1) only	Green LED on
3	Press 'TALK' button once more from the above status	Release the TALK(TX) mode above	Return to the status # 1	Green LED blinking
4	Press 'GRP' button once	Talk(TX) to the latter group (ie: 2)	Listening both groups but talking to the latter groups (ie. 2) only	Orange LED on
5	Press 'GRP' button once more from the above status	Release the TALK(TX) mode above	Return to the status # 1	Green LED blinking
6	Press 'GRP' button once	Talk to the both groups	Listening both groups and talking to both groups as well	Orange quick blink
7	Press 'GRP' button once more from the above status	Release the TALK mode	Return to the status # 1	Green LED blinking

※ The operations are active while the BP screen shows initial 'Normal menu' or in sleep mode.

※ [Pressing 'TALK' button on the status #4 will lead you to the staus #6 with orange LED blinking and pressing 'TALK' button on the status #6 will lead you to the status #4.](#)

The system remembers the latest status mode thus, if you press 'GRP' button on the status #1, it will lead you to either the status #4 or #6.